



division of Fiberglass Systems, Inc.
 4545 Enterprise Street Boise, ID 83705
 ph.: 800-727-9907 fax: 800-627-0929 www.best-bath.com

Installation Instructions

No-Caulk Shower Drain

Compression Gasket - Brass



Installation Instructions:

1. Remove *Inside Compression Nut* and *Compression Gasket*.
2. Apply *Silicone* around the *Shower Drain Hole* on the inside of the shower only.
3. Install the *Drain Body* in the *Shower Drain Hole*.
4. Install the *Rubber Gasket*, *Fiber Gasket* and the *Locking Nut* - Tighten.
5. Install the shower over the drain pipe, or install the pipe later.
6. Slide the *Inside Compression Gasket* into *Drain Body* and slip over pipe. Make sure that the beveled end of *Inside Compression Gasket* is facing up and is flush with pipe surface.
7. Tighten *Inside Compression Nut* into *Drain Body* using the provided tool.

